



OPS DISPENSERS

Installation Guide

1. Find the Stud when possible and center 1 row of the dispenser center holes so the fastener goes into the stud. If there are 2 center rows, just choose the one that will look best.
2. Use the dispenser's back as your template lining up the center holes to the stud and marking the place where the anchors will be placed.
3. Use an anchor suggested by your maintenance department and the size drill bit that that anchor requires.
4. Mark the center holes and the 4 holes on each corner of the dispenser.
Important: Always use the top 2 holes and the bottom 2 holes to anchor the dispenser.
5. Center holes should be used even if there is no available stud.
6. Drill the holes you marked on the wall according to the instructions of the Anchors you have chosen.
7. Place the anchors in the wall and hammer until flush.
8. Place the dispenser against the wall and line it up to the anchor holes.
9. Screw all the fasteners into the wall, not tightening any screw down all the way until you check double check that the dispenser is level.
10. Tighten all the screws into the fasteners.